


Date: %M/%D/%Y

ZVD Quick Installation Guide


Setup System Quickly






Get Familiar with System — Keypad Operations

Select Mode




Set Parameters



To move to previous display

Shift Digits



Modify Data



Set Direction






Installation & Quick-Start

1. Connect Input Power (Do NOT turn on AC Power at this time)

WARNING:
DAMAGES WILL OCCUR IF INPUT AC POWER DOES NOT MATCH ZVD'S INPUT POWER RATING!
CHECK YOUR ZVD, MAKE SURE IF IT IS RATED AS 230VAC OR 460VAC!







Customer supplies input AC power

- **230VAC ZVD**
 - 180 ~ 264 VAC
 - 1-Phase/3-Phase (ONLY FOR ≤3 HP)
 - 3-Phase (ONLY FOR ≥ 5 HP)
 - 47~63 Hz
- **460VAC ZVD**
 - 342 ~ 528 VAC
 - 3-Phase ONLY
 - 47~63 Hz

2. Connect AC Motor Cable

NOTE:

- Do not connect motor thermostat wires P1 and P2 to ZVD terminals P1 and P2.
 - Always refer to pump drawing for correct pump rotation. To change rotation, swap either two of three motor power input cables
- **230 VAC 3-Phase AC Motors**
 - **460 VAC 3-Phase AC Motors**






Installation & Quick-Start (cont'd)


3. Connect Feedback Signal Cable

Hall Effect Sensor (Non-Explosion Proof Area)




| Wire Color | Function | Connect To |
|-------------|-----------------|------------|
| Red | +12VDC | 13 |
| White/Clear | Feedback Signal | 12 |
| Black | Common | 14 |
| Bare | Shielding | 14 |

Encoder (Non-Explosion Proof Area)



| Wire Color | Function | Connect To |
|------------------|---------------------|------------|
| Depend on Sensor | VP — Input Power | 13 |
| | A+ — Signal A+ | 12 |
| | DCM — Signal Common | 14 |
| | A- — Signal A- | 15 |
| | B+ — Signal B+ | 17 |
| | B- — Signal B- | 16 |
| | Shielding | 14 |

Hall Effect Sensor (Explosion Proof Area)



NOTE:

WHEN USING A HALL EFFECT SENSOR OR ENCODER IN A HAZARDOUS ATMOSPHERE, THE OPTIONAL INTRINSICALLY SAFE BARRIER MUST BE USED.

4. Disconnect Coupling (Disconnect Pump from Motor)

5. Turn AC Power On for System



Installation & Quick-Start (cont'd)

6. Configure System

A 5.091:1 reducer and 120 teeth pickup gear is used for the following example.

Change values for the following codes:

| | |
|------------------------------|--|
| Code 00-05 = 30/5.091 = 5.89 | User Unit: Pump RPM |
| Code 00-09 = 3 | Control Method: Vector + PG Control |
| Code 02-00 = 0 | Frequency Source: Keypad |
| Code 02-01 = 0 | Operation Source: Keypad |
| Code 10-08 = 5 | Feedback Signal Detection Time: 5 sec. |
| Code 10-10 = 120 | PG Pulse Range: 120 number of teeth per rev. |
| Code 10-11 = 1 | PG Input: Enabled and single-phase signal |

Click once, the display shows "XX-". Use to change the first 2 digits of the code
 Click again, the display shows "XX-XX". Use to change the last 2 digits of the code
 Click to show the value of this code
 Use to change the value. When finish, click to store the new value.

7. Verify Feedback Signal Manually

- Click "Mode" button until U light lit up
- Use to input a small value, i.e., 5, on the display, and click "RUN" button
- If motor shaft rotates, use to decrease the value until the shaft stops. Meanwhile, make sure "RUN" LED light still lights up and "STOP" light is off
- Wait 5 seconds, "PG-Err" message should pops up for warning no feedback signal. If there is no "PG-Err" message, check the configuration in step 6
- Turn the shaft by a wrench. If the message goes away whenever the shaft turns, it indicates that the installation of feedback sensor is correct. Proceed to the next step (Step 8)
- If "PG-Err" message never goes away, for most of cases, it indicates the air gap between sensor and pickup gear is too large/small (the gap should be maintained to 0.005"). Loosen the sensor, and screw the sensor by hand inward until it hits the inside pickup gear. Back up about 1/8 of a turn (45 degrees). Hold and tighten the sensor. Repeat this step

8. Run System (Do NOT Connect Pump)


Let reducer's shaft run at 60 rpm (**Do not connect pump**)

- Click "Mode" button until U light lit up
- Use to input 60 on the display, and click "RUN" button

9. Refer to "ZVD User Manual" for Further Trouble-shooting

10. Perform/Verify System Configuration (Page 13 on "ZVD User Manual")

11. Read Thru "ZVD User Manual" & System Is Ready




NOTES:


1. MOTOR THERMOSTAT WIRES P1 AND P2 ARE CONNECTED TO TERMINAL STRIP TERMINALS 10 AND 11. DO NOT CONNECT THEM TO ZVD TERMINALS P1 AND P2.
2. WHEN CONNECTING THE FEEDBACK SENSOR, MAKE SURE THAT THE SHIELD AND COMMON ARE CONNECTED TOGETHER AT THE ZVD END.
3. WHEN USING A HALL EFFECT SENSOR, A JUMPER IS REQUIRED FROM A AND B TO DCM OR A "PG-Err" WILL OCCUR IF CODE 00-09 IS SET TO 01 OR 03. IF USING AN ENCODER, REMOVE THE JUMPERS.
4. THE OPTIONAL INTRINSICALLY SAFE BARRIER IS REQUIRED WHEN THE HALL EFFECT SENSOR IS LOCATED IN A HAZARDOUS AREA.
5. THE OPTIONAL EMI FILTER IS USED WHEN CE CERTIFICATION IS REQUIRED. A LARGER CONTROL CABINET MAY BE NECESSARY.
6. 230 VAC 1-PHASE MAY BE SUPPLIED TO A 230 VAC ZVD, 1-3 HP ONLY. CONNECT TO ANY TWO TERMINALS.




ANALOG I/O CONNECTIONS




DISCRETE I/O CONNECTIONS




FEEDBACK CONNECTIONS



INPUT POWER CONNECTIONS



MOTOR CONNECTIONS



NOTE:
WHEN USING A HALL EFFECT SENSOR OR ENCODER IN A HAZARDOUS ATMOSPHERE, THE OPTIONAL INTRINSICALLY SAFE BARRIER MUST BE USED.



CIRCOR Precision Metering, LLC

Zenith Pumps
1710 Airport Road
Monroe, NC 28110

Phone: 704-289-6511

E-mail: service@circor.com