


OPERATION AND MAINTENANCE INSTRUCTIONS

DESMI end suction centrifugal pump

NSLH and NSLV Spacer



DESMI Pumping Technology A/S
Tagholm 1 – DK-9400 Nørresundby – Denmark

Tel.: +45 96 32 81 11
Fax: +45 98 17 54 99
E-mail: desmi@desmi.com
Internet: www.desmi.com

Manual: T1529	Language : English	Revision: F(04/19)
------------------	-----------------------	-----------------------

Special pump No.



Table of Contents:

1. PRODUCT DESCRIPTION	1
1.1 DELIVERY	1
2. TECHNICAL DATA	1
2.1 EXPLANATION OF THE TYPE NUMBER	1
2.2 TECHNICAL DESCRIPTION	2
3. INSTALLATION	4
3.1 MOUNTING/FASTENING	4
3.2 WIRING	4
4. TRANSPORT/STORAGE	5
5. DISMANTLING.....	6
5.1 ACCESS TO IMPELLER.....	6
5.2 DISMANTLING SHAFT SEAL.....	7
5.3 DISMANTLING SEAT.....	7
5.4 DISMANTLING SHAFT WITH BEARINGS	7
5.5 INSPECTION	7
6. ASSEMBLING.....	7
6.1 FITTING SEALING RINGS	7
6.2 FITTING SHAFT WITH BEARINGS.....	7
6.3 FITTING WATER DEFLECTOR.....	8
6.4 FITTING SHAFT SEAL	8
6.5 FITTING IMPELLER	8
6.6 FITTING BEARING HOUSING AND SHAFT SEAL COVER.....	8
6.7 SHAFT	8
6.8 FITTING COUPLING	9
7. FROST PROTECTION	10
8. DISMANTLING.....	10
9. START-UP.....	10
9.1 STARTING	10
10. SYSTEM BALANCING.....	10
11. INSPECTION AND MAINTENANCE	12
11.1 DRAINING THE PUMP	12
11.2 BEARINGS	12
12. REPAIRS.....	14
12.1 ORDERING SPARE PARTS	14
13. OPERATING DATA	14
14. EU DECLARATION OF CONFORMITY	15
15. ASSEMBLY DRAWING AND SPARE PARTS LIST Ø215/265	16
16. ASSEMBLY DRAWING AND SPARE PARTS LIST 65-265 WITH INDUCER	17

17. ASSEMBLY DRAWING AND SPARE PARTS LIST 100-265 WITH INDUCER	18
18. ASSEMBLY DRAWING AND SPARE PARTS LIST Ø330/415	19
19. ASSEMBLY DRAWING AND SPARE PARTS LIST 100-330 WITH INDUCER	20
20. ASSEMBLY DRAWING AND SPARE PARTS LIST 125-330 WITH INDUCER	21
21. ASSEMBLY DRAWING AND SPARE PARTS LIST Ø525	22
22. ASSEMBLY DRAWING AND SPARE PARTS LIST 300-418	23
23. ASSEMBLY DRAWING AND SPARE PARTS LIST 350-525	24
24. DIMENSIONAL SKETCH.	25

1. PRODUCT DESCRIPTION

These operation and maintenance instructions apply to the DESMI NSLH and NSLV Spacer pump.

The pump is a single-stage vertical end suction centrifugal pump equipped with stainless steel shaft, mechanical shaft seal, and closed impeller.

The pump is suitable for the pumping of liquids with temperatures up to 80°C. With special shaft seal up to 120°C. Max. working pressure and number of revolutions are indicated under Operating Data.

The pump is particularly suitable for the pumping of water in connection with cooling systems, cooling of diesel engines, as bilge pumps, ballast pumps, fire pumps, brine pumps, pumps for irrigation, fish farms, water works, district heating, salvage corps, army and navy, etc.

The descriptions in the operation and maintenance instructions are divided into two parts covering the groups **ø215/265** and **ø330/415/525**, as the designs of these two groups are different. The numbers refer to the standard impeller diameter of the pump. E.g.:

ø215/265: Pumps with ø215 or ø265 impellers:

The back of the impeller is equipped with relief blades to reduce the load on the bearings.

ø330/415/525: Pumps with ø330, ø415 or ø525 impellers:

The back and the front of the impeller are equipped with sealing rings and relief holes to reduce the load on the bearings.

1.1 DELIVERY

- Check on delivery that the shipment is complete and undamaged.
- Defects and damages, if any, to be reported to the carrier and the supplier immediately in order that a claim can be advanced.

2. TECHNICAL DATA

The pumps are manufactured in various material combinations which appear from the type number on the name plate. See below.

2.1 EXPLANATION OF THE TYPE NUMBER

All the NSLH and NSLV pumps are provided with a name plate. The type number indicated on the name plate is built up as follows:

NSLHXXX-YYY-MR-Z or NSLVXXX-YYY-MR-Z

XXX: Pressure branch diameter, YYY: Standard impeller diameter

M: The material combination of the pump.

R: The assembly combination of the pump.

Z: Other variants

M may be the following:

- A: Casing and shaft seal cover: Cast iron + cast iron alloy. Impeller and sealing rings: NiAlBz
- B: Casing and shaft seal cover: Cast iron + cast iron alloy. Impeller and sealing rings: Stainless.
- C: All cast iron
- D: Casing and shaft seal cover: Bronze or NiAlBz. Impeller and sealing rings: NiAlBz or stainless steel
- E: Casing and shaft seal cover: NiAlBz and bronze alloy. Impeller and sealing rings: NiAlBz
- S: Casing, shaft seal cover, impeller and sealing rings: SAF2507 and stainless steel alloy.
- U: Nonmagnetic material

The pumps can be delivered in other material combinations according to agreement with the supplier.

R may be the following:

- 02: Monobloc, with bearing in the pump
- 12: Monobloc, without bearing in the pump
- 13: Spacer, light bearing housing
- 14: Spacer, heavy bearing housing
- 15: Spacer, heavy bearing housing and heavy motor bracket (special motor bracket)
- 16: Compact spacer

Z may be the following:

- i : PN16 flanges
- j : PN25 flanges
- k : Special flange
- l : Other shaft seal
- m : BS flanges
- n : ANSI flanges
- o : Shockproof design
- p : Other design
- q : JIS flanges
- r : With inducer

Any use of the pump is to be evaluated on the basis of the materials used in the pump. In case of doubt, contact the supplier.

Pumps in material combinations A and C are primarily used for fresh water.

Pumps in material combination D are primarily used for seawater.

If the pumps are designed for special purposes the following is to be indicated:


- Pump No. :
- Pump type :
- Application :
- Comment :

2.2 TECHNICAL DESCRIPTION

The noise level indicated is the airborne noise including the motor. The noise depends on the motor type supplied, as the noise from the pump can be calculated as the noise level of the motor + 2dB(A). The noise level is for pumps with electric motors.

The capacity of the pump appears from the name plate on the pump. If the pump has been delivered without motor, the pump capacity is to be indicated on the plate when mounting the motor.

The permissible loads on the flanges appear from the following table. The values apply to standard pumps in bronze (Rg5) and cast iron (GG20). As to pumps in SG iron (GGG40), NiAlBz or stainless steel the values are to be increased by factor 1.5.



Pump size	F _y N	F _z N	F _x N	ΣF	M _y Nm	M _z Nm	M _x Nm	Σ Mt
65-215 65-265	650	840	750	1340	510	310	380	700
80-215 80-265 80-330	800	950	850	1500	550	350	400	750
100-215 100-265 100-330 100-415	1000	1250	1150	2000	650	400	500	900
125-215 125-265 125-330 125-415	1250	1600	1430	2500	830	520	650	1160
150-265 150-330 150-415	1500	1900	1700	2950	1000	650	800	1400
200-265 200-330 200-415 200-525	2000	2520	2260	3920	1330	860	1060	1860
250-330 250-415 250-525	2500	3150	2820	4900	1770	1140	1400	2470
300-415 300-418 300-525	3000	3750	3350	5860	2750	1900	2200	4000
350-525	3500	4370	3920	6840	3630	2500	2930	5300

In connection with the permissible loads on the flanges the following is to be observed:

$$\left(\frac{\sum F_{calc}}{\sum F} \right)^2 + \left(\frac{\sum M_{calc}}{\sum M_t} \right)^2 < 2$$

Where index "calc" are the values calculated by the user.

At the same time none of the forces or moments may exceed the indicated figure multiplied by 1.4.

3. INSTALLATION

3.1 MOUNTING/FASTENING

The pump should be mounted and fastened on a solid base plate with a flat and horizontal surface to avoid distortion.

The max. permissible loads on the flanges stated in paragraph 2.2 are to be observed.



At installations pumping hot or very cold liquids, the operator must be aware that it is dangerous to touch the pump surface and, consequently, he must take the necessary safety measures.

3.2 WIRING



Wiring to be carried out by authorised skilled workmen according to the rules and regulations in force.

4. TRANSPORT/STORAGE

The weights of the pumps in A and D combination (without motor) are stated in the following table, and the pumps are to be lifted as shown below.


Pump size	Weight in kg A / D-combination	Pump size	Weight in kg A / D-combination
65-215	150 / 155	150-415	420 / 455
65-265	195 / 200	150-265	256 / 277
80-330	295 / 310	200-330	432 / 473
80-215	160 / 170	200-415	548 / 592
80-265	212 / 224	200-525	885 / 950
100-330	317 / 335	200-265	323 / 327
100-415	354 / 366	250-330	490 / 537
100-215	165 / 175	250-415	602 / 657
100-265	223 / 238	250-525	930 / 1004
125-330	320 / 345	300-415	690 / 758
125-415	370 / 400	300-418	784 / 713
125-215	165 / 180	300-525	1112/1214
125-265	258 / 281	350-525	1279/-
150-330	365 / 395		

The weights of the pumps in E and S (without motor) are equivalent to pumps in A code.

The pump is to be stored in a dry area.

Before shipment the pump is to be fastened securely on pallets or the like.

The pump is to be lifted in the following way:



The lifting straps must not bear against sharp edges and corners.

5. DISMANTLING

5.1 ACCESS TO IMPELLER

The numbers in brackets refer to the position numbers on the assembly drawing.

Dismantle guard (69).

ø215/265

Remove Allen screws (77) between coupling part motor (71) and spacer (72) and the screws (76), which hold the flexible coupling (74) to the coupling part pump (70). It is not necessary to remove the screws (also 76) which hold the flexible coupling to the spacer. After a vertical pull downwards take out the spacer (72). Loosen the pointed screw (73) and pull the coupling part pump (70) off the shaft. Dismantle the copper pipe (58). Remove Allen screws (22) which hold the shaft seal cover (20) to the pump casing. Remove the shaft seal cover from the pump casing by means of the pointed screws (86). The bearing housing with shaft and impeller can now be lifted up from the pump as a unit, and the impeller can be inspected.

ø330/415/525

Remove Allen screws (76) at each end of the coupling, and remove the spacer (72). Loosen the pointed screw (73) and pull the coupling part pump (70) off the shaft. Dismantle the copper pipe (58). Remove set screws (22) with washers (23) which hold the shaft seal cover to the pump casing. Remove the shaft seal cover from the pump casing by means of the pointed screws (86). The shaft seal cover and the bearing housing with shaft and impeller can now be lifted up from the pump as a unit, and the impeller can be inspected.

5.2 DISMANTLING SHAFT SEAL

ø215/265

Remove nut (6). Pull off the impeller, and remove sunk key (9). Remove Allen screws (19), which hold the bearing housing to the shaft seal cover, pull shaft seal cover and bearing housing apart, by which the shaft seal (10) and water deflector (11) are pulled off the shaft.

ø330/415/525

Remove set screw (6). Pull off the impeller, and remove sunk key (9). Remove set screws (19), which hold the bearing housing to the shaft seal cover, pull shaft seal cover and bearing housing apart, by which the shaft seal (10) is pulled off the shaft.

5.3 DISMANTLING SEAT

Press out the seat from behind the shaft seal cover.

5.4 DISMANTLING SHAFT WITH BEARINGS

Before dismantling the shaft with bearings, remove the sunk key (16). The shaft can now be pulled out of the bearing housing allowing inspection of the bearings.

5.5 INSPECTION

When the pump has been dismantled, check the following parts for wear and damage:

- Sealing rings/impeller: Max. clearance 0.4-0.5 mm measured in radius.
- Shaft seal/shaft seal cover: Check the seat for flatness and cracks.
Check the rubber parts for elasticity.
- Bearings: Replace in case of wear and noise.

6. ASSEMBLING

6.1 FITTING SEALING RINGS

When fitted, the sealing ring (4) in the pump casing (1) is to bear against the shoulder of the pump casing.

ø330/415/525

When fitted, the sealing ring (27) in the shaft seal cover (20) is to bear against the shoulder of the shaft seal cover.

6.2 FITTING SHAFT WITH BEARINGS

Lead shaft with bearings into the bearing housing. Fit sunk key (16).

ø330/415/525

Fit cover under bearing (26).

6.3 FITTING WATER DEFLECTOR

ø215/265

Assemble the bearing housing and the shaft seal cover. Lead the water deflector (11) over the shaft until it touches the shaft seal cover and then further 1-1.5 mm into the shaft seal cover.

ø330/415/525

Lead the water deflector (11) over the shaft until it touches the cover under bearing (26) and then further 1-1.5 mm towards the cover under bearing. Assemble the bearing housing and the shaft seal cover.

6.4 FITTING SHAFT SEAL

Before fitting the seat, clean the recess in the shaft seal cover. When fitting the seat, remove the protective coating without scratching the lapped surface. Dip the outer rubber ring of the seat into soapy water. Now press the seat into place with the fingers and check that all parts are correctly imbedded.

If it is necessary to use tools for assembling, then protect the sliding surface of the seat to prevent it from being scratched or cut. Lubricate the inner diameter of the slide ring rubber bellows with soapy water and push it over the shaft. The use of a fitting bush as shown on the assembly drawing is recommended to avoid that the rubber bellows is cut.

Push the slide ring over the shaft with the hand. If the rubber bellows is tight, use a fitting tool and take care that the slide ring is not damaged. If the carbon ring is not fixed, it is important to check that it is fitted correctly, i.e. the chamfered/lapped side is to face the seat. The carbon ring can be held by a little grease.

When using soapy water on the shaft, the bellows will settle and seat in about 15 minutes, and until then tightness should not be expected. After start, check by viewing the leak hole at the bottom of the bearing housing that there are no leaks.

6.5 FITTING IMPELLER

Fit the sunk key in the shaft and lead the impeller towards the shoulder of the shaft. Take care that the ring at the end of the shaft seal spring locates in the recess of the impeller. Secure the impeller with washers (7 and 8) and a nut (ø215/265) or a set screw (ø330/415/525).

6.6 FITTING BEARING HOUSING AND SHAFT SEAL COVER

Place the O-ring (21) between pump casing and shaft seal cover on the shaft seal cover where it can be held with a little grease. However, check the material of the O-ring first. As standard the material is nitrile, but it might be EPDM which will be damaged by mineral grease. Use soft soap or silicone grease for EPDM. Fit and fasten bearing housing and shaft seal cover. Screw the pointed screw (86) back into the shaft seal cover before tightening. Insert the copper pipe (58).

6.7 SHAFT

When the pump has been assembled, check that the shaft rotates freely.

6.8 FITTING COUPLING

When the motor and pump is bolted fully together (via the pump Spacer motor bracket) then there are no further requirements for checking the coupling alignment. But please ensure that suitable shims are used (where required) below pump and motor feet in order to avoid deformations in pump and/or motor when tightened down on the foundation / base frame.

ø215/265

Fit the flexible coupling (74) to the spacer (72) by means of the Allen screws (76) which are tightened up with torque according to the table below. Check that the aluminum insert in the rubber part does not rotate during tightening as it may damage the coupling. To prevent this, apply a little grease to the bolts under the bolt head. The Allen screws (76) can be used again and up to 3 times before they are to be replaced by new original bolts to secure the locking function. Do not use Loctite as it will damage the rubber element.

Fix the spacer with the flexible coupling to the coupling part motor (71) by means of the Allen screws (77) and lock nuts (79), also with torque according to the table below. In order to secure the bolt connection fit a new lock nut or secure with a locking means.

Check that the distance, cf. the table below, between spacer and coupling part pump corresponds to the actual coupling size which appears from the coupling element itself. Fit the flexible coupling to the coupling part pump by means of the Allen screws (76) which are to be greased a little under the bolt head and tightened with the torque stated.

Thread	Torque	Coupling element	Distance
M8	25 Nm	V1700-0832	4 mm
M10	50 Nm	V1700-1042	4 mm
M12	90 Nm	V1700-1242	6 mm
M14	140 Nm	V1700-1442	6 mm

ø330/415/525

Check Allen screws (76) and coupling bushes (74) for damage and clean these with a cloth. Replace them in case of damage.

Remove grease from the screw threads by means of benzene, and clean the threaded holes in the coupling halves for pump and motor by means of pressure air. If new coupling halves are mounted, also remove grease from the threaded holes by means of benzene.

Place coupling bushes (74) in the top holes of the spacer (72), the chamfering on the bushes is to face downwards. Place the coupling bush in the bottom holes of the spacer, the chamfering on the bushes is to face upwards. Hold the hand under the spacer and the bottom coupling bushes and carefully push the spacer into place.

Apply Loctite type 242 on the Allen screws (Loctite 242 is recommended as it will allow dismantling) and tighten all screws with the hand. It might be necessary to push the spacer a little until the screws have located in the thread and you feel that the spacer has found the right position.

Tighten the screws with a torque wrench at 55 Nm. As motor/pump shaft will rotate during this operation it is necessary to hold the spacer by wedging a pin bolt, a piece of flat bar or the like between the two following screw heads in order to lock the system while the screws are tightened. Fit guard (69).

7. FROST PROTECTION

Pumps that are not in operation during frost periods are to be drained to avoid frost damage. Remove the plug (3) at the bottom to empty the pump. Alternatively, it is possible to use anti-freeze liquids in normal constructions.

8. DISMANTLING



Before dismantling the pump make sure that it has stopped. Empty the pump of liquid before it is dismantled from the piping system. If the pump has been pumping dangerous liquids you are to be aware of this and take the necessary safety measures. If the pump has been pumping hot liquids, take great care that it is drained before it is removed from the piping system.

9. START-UP



A centrifugal pump will not function until it has been filled with liquid between the foot valve and somewhat above the impeller of the pump.

The liquid also serves as coolant for the shaft seal. In order to protect the shaft seal the pump must not run dry.

ATTENTION

For safety reasons the pump is only allowed to operate against closed discharge valve for a short time (max. 5 minutes and at a max. temperature of 80°C for standard pumps). Otherwise there is a risk of damage to the pump and, at worst, of a steam explosion. If the pump is not monitored, the installation of a safety device is recommended.

9.1 STARTING

Before starting the pump check that:

- the shaft rotates freely without jarring sounds.
- the pump casing and the suction line are filled with liquid.

Start the pump for a moment to check the direction of rotation. If the direction is correct (i.e. in the direction of the arrow) the pump may be started.

10. SYSTEM BALANCING

It is often difficult to calculate a manometric delivery head in advance. It is, however, decisively important to the quantity of liquid delivered.

A considerably smaller delivery head than expected will increase the quantity of liquid delivered, causing increased power consumption and perhaps cavitation in pump and piping. In the pump the impeller may show signs of heavy erosion caused by cavitation (corrosion) which may at times render an impeller unfit for use in a very short time. Not unusually do similar erosions occur in pipe bends and valves elsewhere in the piping system.

Therefore, after start-up, it is necessary to check either the quantity of liquid delivered or the power consumption of the pump e.g. by measuring the current intensity of the connected motor. Together with a reading of the differential pressure the quantity of water delivered can be determined against the characteristics of the pump.

Should the pump not function as intended, please proceed according to the fault-finding list. Bear in mind, though, that the pump was carefully checked and tested at the factory and that the majority of faults stem from the piping system.

FAULT	CAUSE	REMEDY
The pump has no or too low capacity	<ol style="list-style-type: none"> 1. Wrong direction of rotation 2. Piping system choked 3. The pump is choked 4. Suction line leaks Pump takes air 5. Suction lift too high 6. Pump and piping system wrongly dimensioned 	Change direction of rotation to clockwise when viewed from shaft end (the direction of the arrow) Clean or replace Clean the pump Find the leakage, repair the fault, non-return valve not submerged Check data sheet Q/H curve and NPSH or contact DESMI As 5
The pump uses too much power	<ol style="list-style-type: none"> 1. Counter-pressure too low 2. The liquid is heavier than water 3. Foreign body in pump 4. Electric motor is running on 2 phases 	Insert orifice plate or check valve/Contact DESMI Contact DESMI Dismantle the pump, remove the cause Check fuses, cable connection, and cable
The pump makes noise	<ol style="list-style-type: none"> 1. Cavitation in pump 	Suction lift too high/ Suction line wrongly dimensioned/ Liquid temperature too high

11. INSPECTION AND MAINTENANCE

Inspect the shaft seal for leaks at regular intervals.

- Before inspection of a pump without guard check that the pump cannot be started unintentionally.
- The system is to be without pressure and drained of liquid.
- The repairman must be familiar with the type of liquid which has been pumped as well as the safety measures he is to take when handling the liquid.

11.1 DRAINING THE PUMP

When the piping system has been drained, note that there is still liquid in the pump. Remove the liquid by dismantling the pipe plug (3) at the bottom of the pump.

11.2 BEARINGS

ø215/265

The bearings are dimensioned for a nominal life of 25,000 working hours and are to be relubricated according to the below table.

Light bearing housing (combination 13):

The bearings are lubricated for life and require no attention but are to be replaced in case of noise or bearing wear. In connection with replacement, the lower bearing is to be mounted with an RS - sealing facing downwards, fill the bearing itself with grease and place a grease bead on the bearing towards the shaft in a quantity corresponding to the table below.

Heavy bearing housing (combination 14):

Only the upper bearing (15) is lubricated for life, whereas the lower is to be relubricated through the lubricator nipple (84) in accordance with the table below. The replacement of bearings to be made under the same conditions and according to the same procedure as for combination 13, however, the RS - sealing is not to be considered.

ø330/415/525

The bearings are dimensioned for a nominal life of 100,000 working hours and are to be relubricated according to the below table.

Light bearing housing (combination 13):

The bearings are relubricated through the lubricator nipples (84) at top and bottom of the bearing housing (18). In connection with replacement, the bearings are to be mounted with the RS - sealing facing downwards, fill the bearing itself with grease and place a grease bead on the bearing towards the shaft in a quantity corresponding to the table below.

Heavy bearing housing (combination 14):

Both bearings are relubricated through lubricator nipples (84) at top and bottom of the bearing housing (18). See instructions for ø215/265. The top bearing (15) is to be mounted with the RS - sealing facing downwards, fill the bearing itself with grease and place a grease bead on the bearing towards the shaft in a quantity corresponding to the table below.

Pump size	Assembly	Interval	Quantity Bottom bearing (13)	Quantity Top bearing (15)
ø215/265	Light bearing housing	Lubricated for life	40 g	Lubricated for life
ø215/265	Heavy bearing housing	8000 hours	65 g	Lubricated for life
80-330 100-330 125-330 100-415 125-415	Light bearing housing	4500 hours	30 g	15 g
150-330 200-330 250-330 150-415	Heavy bearing housing	4500 hours	40 g	20 g
200-415 250-415 300-415 300-418	Heavy bearing housing	4500 hours	50 g	25 g
200-525 250-525 300-525 350-525	Heavy bearing housing	4500 hours	80 g	35 g

If the pump liquid temperature is below 80 °C the following types of grease are recommended:

ESSO	Beacon 2
BP	Energrease LS EP 2
Shell	Gadus S5 V100 2
Mobil	Mobil lux grease EP 2 eller Mobil plex 47
Castrol	Spheerol AP 2
Texaco	Multifak EP 2
Q8	Rembrandt EP 2 eller Rubens
Statoil	UniWay Li 62

If the pump liquid temperature is above 80 °C, high-temperature grease is recommended, e.g. SKF LGHP2.

12. REPAIRS

12.1 ORDERING SPARE PARTS

When ordering spare parts please always state pump type, serial No. (appears on the name plate of the pump), position No. on the assembly drawing and designation on the spare parts list.

13. OPERATING DATA

The following working pressures (pressure in piping incl. the pressure increase caused by the pump) and number of revolutions are allowed in standard pumps.

Pump size	Max. working pressure [bar] Bronze / Cast iron	Max. working pressure [bar] SG-iron	Max. RPM Light/heavy bearing housing	Pump size	Max. working pressure [bar] Bronze / Cast iron	Max. working pressure [bar] SG-iron	Max. RPM
65-215	16	25	1800/3600	150-415	9 / 13	25	1800
65-265	14.5	25	1800/3600	150-265	10	25	1800
80-330	15	25	3600/---	200-525	14	25	1800
80-215	13	25	1800/3600	200-330	7 / 13	25	1800
80-265	14.5	25	1800/3600	200-415	9 / 13	25	1800
100-330	11 / 14	25	3000/3600	200-265	10 / 12.5	25	1800
100-415	10 / 12.5	25	1800/---	250-330	7 / 12	25	1800
100-215	12.5	25	1800/3600	250-415	9 / 12	25	1800
100-265	14.5	25	1800/3600	250-525	14	25	1800
125-330	11 / 12	25	3000/---	300-415	9 / 12	25	1800
125-415	9 / 13	25	1800	300-418	6/16	25	1600
125-215	8	25	1800	300-525	14	25	1800
125-265	7	25	1800	350-525	-/16	25	1600
150-330	7 / 13	25	1800				

Notice: Some pump combinations allow higher speeds than stated in the table—see actual pump name plate.

The max. working pressure for NiAlBz and stainless steel pumps is 1.5 times max. working pressure for bronze (RG5).

The above-mentioned max. working pressure is a design value – delivered pumps are pressure tested according to actual application requirements and actual flange standards.

For instance the above-mentioned max. working pressure is **NOT** valid for pumps approved by a classification society. Pumps approved by classification societies have been pressure tested according to the requirements of these societies, i.e. a test pressure of 1.5 x the permissible working pressure. The test pressure is stated in the test certificate and stamped into the discharge flange of the pump.

14. EU DECLARATION OF CONFORMITY

DESMI PUMPING TECHNOLOGY A/S, hereby declare that our pumps of the NSLH and NSLV Spacer type are manufactured in conformity with the following essential safety and health requirements in the COUNCIL DIRECTIVE 2006/42/EC on machines, Annex 1.

The following harmonized standards have been used:

EN/ISO 13857:2008	Safety of machinery. Safety distances to prevent danger zones being reached by the upper limbs
EN 809:1998 + A1:2009	Pumps and pump units for liquids – Common safety requirements
EN12162:2001+A1:2009	Liquid pumps – Safety requirements – Procedure for hydrostatic testing
EN 60204-1:2006/A1:2009	Safety of machinery – Electrical equipment of machines (item 4, General requirements)
Ecodesign Directive (2009/125/EC)	Water pumps: Commission Regulation No 547/2012. Applies only to water pumps marked with the minimum efficiency index MEI. See pump nameplate.

Pumps delivered by us connected with prime movers are CE-marked and comply with the above requirements.

Pumps delivered by us without prime movers (as partly completed machinery) must only be used when the prime mover and the connection between prime mover and pump comply with the above requirements.


Nørresundby, March 05 2019



Henrik Mørkholt Sørensen
Managing Director


DESMI Pumping Technology A/S
Tagholm 1
9400 Nørresundby

15. ASSEMBLY DRAWING AND SPARE PARTS LIST Ø215/265



- 1 Pump casing
 - 2 Pipe plug
 - 3 Pipe plug
 - 4 Sealing ring
 - 5 Impeller
 - 6 Nut
 - 7 Spring collar
 - 8 Washer
 - 9 Sunk key
 - 10 Mech. shaft seal
 - 11 Water deflector
 - 12 Ring lock
 - 13 Ball bearing
 - 14 Support disc
 - 15 Ball bearing
 - 16 Sunk key
 - 17 Shaft
 - 18 Bearing housing
 - 19 Allen screw
 - 20 Shaft seal cover
 - 21 O-ring
 - 22 Allen screw
 - 58 Copper pipe (For NSLV)
 - 59 Hexagon nipple
 - 60 Set screw
 - 63 Bracket
 - 64 Set screw
 - 67 Set screw
 - 69 Guard
 - 70 Coupling part pump
 - 71 Coupling part motor
 - 72 Spacer
 - 73 Pointed screw
 - 74 Elastomer
 - 76 Allen screw
 - 77 Allen screw
 - 79 Nut
 - 81 Sealing washer
 - 84 Lubricator nipple *)
 - 86 Pointed screw
 - 96 Manometer
 - 97 Reducing nipple
 - 98 Hexagon nipple
 - 99 T-piece
 - 100 Bulkhead connection
 - 101 Screw cap
 - 103 Copper pipe
 - 106 Manometer cock
 - 107 Pipe plug
 - 109 Set screw
 - 110 Manometer fitting
- *) 84 only combination 14


16. ASSEMBLY DRAWING AND SPARE PARTS LIST 65-265 WITH INDUCER



- 1 Pump casing
- 2 Pipe plug
- 3 Pipe plug
- 4 Sealing ring
- 5 Impeller
- 6 Round nut
- 7 Inducer
- 8 Sunk key
- 9 Sunk key
- 10 Mech. shaft seal
- 11 Water deflector
- 12 Ring lock
- 13 Ball bearing
- 14 Support disc
- 15 Ball bearing
- 16 Sunk key
- 17 Shaft
- 18 Bearing housing
- 19 Allen screw
- 20 Shaft seal cover
- 21 O-ring
- 22 Allen screw
- 23 Domed cap nut
- 24 Spring washer
- 25 Stud
- 58 Copper pipe (For NSLV)
- 59 Hexagon nipple
- 60 Set screw
- 63 Bracket
- 64 Set screw
- 67 Set screw
- 69 Guard
- 70 Coupling part pump
- 71 Coupling part motor
- 72 Spacer
- 73 Pointed screw
- 74 Elastomer
- 76 Allen screw
- 77 Allen screw
- 79 Nut
- 81 Sealing washer
- 84 Lubricator nipple *)
- 86 Point screw
- 96 Manometer
- 97 Reducing nipple
- 98 Hexagon nipple
- 99 T-piece
- 100 Bulkhead connection
- 101 Screw cap
- 103 Copper pipe
- 106 Manometer cock
- 107 Pipe plug
- 109 Set screw
- 110 Manometer fitting
- 111 Extend pipe
- 112 O-ring
- 113 Set screw
- 114 Nut
- 201 Base frame

*) 84 only combination 14

17. ASSEMBLY DRAWING AND SPARE PARTS LIST 100-265 WITH INDUCER




- 1 Pump casing
- 2 Pipe plug
- 3 Pipe plug
- 4 Sealing ring
- 5 Impeller
- 6 Round nut
- 7 Inducer
- 8 Sunk key
- 9 Sunk key
- 10 Mech. shaft seal
- 11 Water deflector
- 12 Ring lock
- 13 Ball bearing
- 14 Support disc
- 15 Ball bearing
- 16 Sunk key
- 17 Shaft
- 18 Bearing housing
- 19 Allen screw
- 20 Shaft seal cover
- 21 O-ring
- 22 Allen screw
- 23 Domed cap nut
- 24 Intermediate flange
- 25 Allen screw
- 26 Spring washer
- 27 Stud
- 58 Copper pipe (For NSLV)
- 59 Hexagon nipple
- 60 Set screw
- 63 Bracket
- 64 Set screw
- 67 Set screw
- 69 Guard
- 70 Coupling part pump
- 71 Coupling part motor
- 72 Spacer
- 73 Pointed screw
- 74 Elastomer
- 76 Allen screw
- 77 Allen screw
- 79 Nut
- 81 Sealing washer
- 84 Lubricator nipple *)
- 86 Pointed screw

*) 84 only combination 14

*) 24, 25 only be used when the motor size ≥ 225


18. ASSEMBLY DRAWING AND SPARE PARTS LIST Ø330/415



- 1 Pump casing
- 2 Pipe plug
- 3 Pipe plug
- 4 Sealing ring
- 5 Impeller
- 6 Set screw
- 7 Spring collar
- 8 Washer
- 9 Sunk key
- 10 Mech. shaft seal
- 11 Water deflector
- 12 Ring lock
- 13 Ball bearing
- 14 Grease valve ring*
- 15 Ball bearing
- 16 Sunk key
- 17 Shaft
- 18 Bearing housing
- 19 Set screw
- 20 Shaft seal cover
- 21 O-ring
- 22 Set screw
- 23 Lock washer
- 26 Cover under bearing
- 27 Sealing ring 2
- 58 Copper pipe (for NSLV)
- 59 Hexagon nipple
- 60 Set screw
- 61 Hexagon nipple
- 63 Bracket
- 64 Set screw
- 67 Set screw
- 69 Guard
- 70 Coupling part pump
- 71 Coupling part motor
- 72 Spacer
- 73 Pointed screw
- 74 Coupling bush
- 76 Allen screw
- 81 Sealing washer
- 84 Lubricator nipple
- 86 Pointed screw
- 96 Manometer
- 97 Reducing nipple
- 98 Hexagon nipple
- 99 T-piece
- 100 Bulkhead connection
- 101 Screw cap
- 103 Copper pipe
- 104 Screw
- 105 Pipe clamp
- 106 Manometer cock
- 107 Pipe plug
- 109 Set screw
- 110 Manometer fitting


*) Support disc in comb. 13.

19. ASSEMBLY DRAWING AND SPARE PARTS LIST 100-330 WITH INDUCER



- 1 Pump casing
- 2 Pipe plug
- 3 Pipe plug
- 4 Sealing ring
- 5 Impeller
- 7 Inducer
- 8 Sunk key
- 9 Sunk Key
- 10 Mech. shaft seal
- 11 Water deflector
- 12 Ring lock
- 13 Ball bearing
- 14 Grease valve ring*
- 15 Ball bearing
- 16 Sunk key
- 17 Shaft
- 18 Bearing housing
- 19 Set screw
- 20 Shaft seal cover
- 21 O-ring
- 22 Set screw
- 23 Lock washer
- 24 Intermediate flange
- 25 Allen screw
- 26 Cover under bearing
- 27 Sealing ring 2
- 58 Copper pipe (for NSLV)
- 59 Hexagon nipple
- 60 Set screw
- 63 Bracket
- 64 Set screw
- 67 Set screw
- 69 Guard
- 70 Coupling part pump
- 71 Coupling part motor
- 72 Spacer
- 73 Pointed screw
- 74 Coupling bush
- 76 Allen screw
- 80 Round nut
- 81 Sealing washer
- 84 Lubricator nipple
- 86 Pointed screw
- 97 Spring washer
- 98 Domed cap nut
- 99 Stud
- 111 Inducer pipe
- 112 O ring
- 113 Set screw
- 114 Nut
- 201 Base frame


20. ASSEMBLY DRAWING AND SPARE PARTS LIST 125-330 WITH INDUCER



- 1 Pump casing
- 2 Pipe plug
- 3 Pipe plug
- 4 Sealing ring
- 5 Impeller
- 6 Stop ring
- 7 Round nut
- 8 Sunk key
- 9 Inducer
- 10 Mech. shaft seal
- 11 Water deflector
- 12 Ring lock
- 13 Ball bearing
- 14 Grease valve ring*
- 15 Ball bearing
- 16 Sunk key
- 17 Shaft
- 18 Bearing housing
- 19 Set screw
- 20 Shaft seal cover
- 21 O-ring
- 22 Set screw
- 23 Lock washer
- 26 Cover under bearing
- 27 Sealing ring 2
- 28 Sunk key
- 29 Stud
- 30 Domed cap nut
- 31 Spring washer
- 58 Copper pipe (for NSLV)
- 59 Hexagon nipple
- 60 Set screw
- 61 Hexagon nipple
- 63 Bracket
- 64 Set screw
- 67 Set screw
- 69 Guard
- 70 Coupling part pump
- 71 Coupling part motor
- 72 Spacer
- 73 Pointed screw
- 74 Coupling bush
- 76 Allen screw
- 81 Sealing washer
- 84 Lubricator nipple
- 86 Pointed screw
- 111 Inducer pipe
- 112 O ring
- 113 Set screw
- 114 Nut

*) Support disc in comb. 13.

21. ASSEMBLY DRAWING AND SPARE PARTS LIST Ø525




- 1 Pump casing
- 2 Pipe plug
- 3 Pipe plug
- 4 Sealing ring
- 5 Impeller
- 6 Set screw
- 7 Spring collar
- 8 Washer
- 9 Sunk key
- 10 Mech. shaft seal
- 11 Water deflector
- 12 Ring lock
- 13 Ball bearing
- 14 Grease valve ring*
- 15 Ball bearing
- 16 Sunk key
- 17 Shaft
- 18 Bearing housing
- 19 Set screw
- 20 Shaft seal cover
- 21 O-ring
- 22 Set screw
- 23 Lock washer
- 26 Cover under bearing
- 27 Sealing ring 2
- 38 Guide plate
- 39 Sunk screw
- 45 Guide plate
- 46 Allan screw
- 47 Washer
- 58 Copper pipe
- 60 Set screw
- 61 Hexagon nipple
- 63 Bracket
- 64 Set screw
- 67 Set screw
- 69 Guard
- 70 Coupling part pump
- 71 Coupling part motor
- 72 Spacer
- 73 Pointed screw
- 74 Coupling bush
- 76 Allen screw
- 81 Sealing washer
- 84 Lubricator nipple
- 86 Pointed screw
- 96 Manometer
- 97 Reducing nipple
- 98 Hexagon nipple
- 99 T-piece
- 100 Bulkhead connection
- 101 Screw cap
- 103 Copper pipe
- 104 Screw
- 105 Pipe clamp
- 106 Manometer cock
- 107 Pipe plug
- 109 Set screw
- 110 Manometer fitting

*) 14 Support disc in comb. 13.

*) 45, 46 and 47 only in NSLH and NSLV300-525


22. ASSEMBLY DRAWING AND SPARE PARTS LIST 300-418



- 1 Pump casing
- 2 Pipe plug
- 3 Pipe plug
- 4 Sealing ring
- 5 Impeller
- 6 Set screw
- 7 Spring collar
- 8 Washer
- 9 Sunk key
- 10 Mech. shaft seal
- 11 Water deflector
- 12 Ring lock
- 13 Ball bearing
- 14 Grease valve ring*
- 15 Ball bearing
- 16 Sunk key
- 17 Shaft
- 18 Bearing housing
- 19 Set screw
- 20 Shaft seal cover
- 21 O-ring
- 22 Set screw
- 23 Lock washer
- 26 Cover under bearing
- 27 Sealing ring 2
- 38 Guide plate
- 39 Sunk screw
- 45 Guide plate
- 46 Allan screw
- 47 Washer
- 58 Copper pipe
- 60 Set screw
- 61 Hexagon nipple
- 63 Bracket
- 64 Set screw
- 67 Set screw
- 69 Guard
- 70 Coupling part pump
- 71 Coupling part motor
- 72 Spacer
- 73 Pointed screw
- 74 Coupling bush
- 76 Allen screw
- 81 Sealing washer
- 84 Lubricator nipple
- 86 Pointed screw

*) 14 Support disc in comb. 13.

23. ASSEMBLY DRAWING AND SPARE PARTS LIST 350-525



*) 14 Support disc in comb. 13.

24. DIMENSIONAL SKETCH.

Please require a dimensional sketch of the actual pump from DESMI