



- NOTES:
1. BASIC WEIGHT DOES NOT INCLUDE SHAFT, IMPELLERS OR MOTOR.
 2. ALL DIMENSIONS ARE IN INCHES.

DIMENSIONS										
CASE SIZE	A	B	ØC	D	E	F	J	ØK	L	BASIC ^① WGT. (LBS)
2	14.0	10.0	0.75	0.63	8.8	37.6	5.8	5.5	5.2	190
3	16.0	10.0	0.75	0.75	10.2	43.8	7.4	6.0	5.8	290
4	19.0	10.0	0.88	1.00	11.7	48.7	9.3	6.75	6.9	470
5	23.0	13.0	1.00	1.25	14.7	56.0	11.5	6.75	7.5	710
7	28.0	16.0	1.13	1.25	16.7	68.2	12.8	10.2	9.8	1210
8	34.0	20.0	1.38	1.50	19.5	83.1	14.8	11.8	11.5	2010
9	43.0	26.0	1.38	1.50	27.6	91.1	16.9	13.0	13.3	4160

J: MINIMUM HARDWARE CLEARANCE REQUIRED IN MOUNTING STRUCTURE.

FOR REFERENCE ONLY

* ALL DIMENSIONS AND WEIGHTS ARE FOR REFERENCE ONLY UNLESS THE DRAWING IS CERTIFIED.
 * ALL EQUIPMENT DESIGN AND APPLICATION DATA SHOWN HEREIN IS CONFIDENTIAL AND THE PROPERTY OF BRAWN MIXER. NO USE OR DISCLOSURE THEREOF MAY BE MADE WITHOUT OUR WRITTEN PERMISSION.

DRAWN BY:BSB DATE:10/8/2018 © 2018
 APPROVED BY: DATE:

BRAWN MIXER
 AN INNOVATIVE COMPANY

12838 STAINLESS DR
 HOLLAND, MI 49424
 PH: 616-399-5600
 FAX: 616-399-3084

MIXER MODEL
BTR
 OPEN TANK MOUNTED MIXER
 DIMENSION AND ASSEMBLY DRAWING

DWG. NO. **B- TK0188** REV.